


NOTE: CONNECT THE WIRING BEFORE PROCEEDING WITH MECHANICAL ASSEMBLY



INSTALLATION:

1. Install anchors or drill holes as necessary for the Wall or Ceiling support
2. Connect all necessary wires for supply and sync.
3. Install retaining screws fixing the wall or ceiling adapter to the SELENA clock
4. Install the clock assembly on the wall or ceiling using heavy bolts or screws
5. Switch the supply power on and using the Remote Control, enable all required Sync modes (the modes may be changed at any time via the remote control without disconnecting the power)

NOTE:

- | | |
|--|--|
| A) For Power line Carrier Sync: | SELENA with option #724 or 724RS needed |
| B) For Twisted Pair (RS-485 or RS-232) Sync: | SELENA with option #725 or 725232 needed |
| C) For 2-wire ASCII/BCD Sync: | SELENA with option #726 needed |
| D) For NTP Ethernet / Internet Sync: | SELENA with option #725NTP needed |
| E) For GPS Sync: | SELENA with option #725GPS needed |